

# **Installation Instructions**

# Universal Guide For Dual Exit Exhaust





### topspeedauto.com

972-233-0888

Congratulations on purchasing a TOP SPEED Performance premium exhaust system! Please read and understand these instructions before beginning to work on installing the exhaust. If you do not fully understand the instructions, please give us a call at 972-233-0888 or email us at <a href="mailto:info@topspeedauto.com">info@topspeedauto.com</a>.



Disclaimer: ALL TOP SPEED Performance products are deemed "off-road/race" use only. Check your local state laws regarding emissions before using any product. Please check the vehicle code for your state and additional laws.

We recommend that this exhaust be **installed by someone qualified in this line of work or certified mechanic** with access to appropriate tools. It also recommended that a **lift be used during the installation.** 

It is **your responsibility to follow the instructions** provided for this exhaust and exercise all safety precautions.

#### Removal of original exhaust

- Make sure to have additional help to assist you in removing the original exhaust system as the original exhaust system might be heavy
- If original system is rusty make sure to soak with plenty of lubricant example WD-40

#### First operation:

- Make sure no part of the exhaust system is touching before starting
- Turn the car on and check for any leaks. Be careful as it can get hot if left on for too long.
- It is normal to have white smoke and a smell that comes from the exhaust upon the first start and operation as it breaks in.

#### Maintenance:

- Please do not use any acidic chemicals or abrasive materials when cleaning your exhaust
- We recommend you **only** use water and/or automotive soap when cleaning burnt tips.
- Check bolts periodically to ensure they don't loosen

#### Content (most systems)

- Muffler(s)
- Front pipe(s) or X-pipe
- Mid pipe(s)
- Gasket(s)
- Hardware

#### Recommended Tools (may not be exact)

- Socket Wrench/Wrench
  - 10 mm
  - 14 mm
  - 16 mm
  - 17 mm
  - 18 mm
  - 19 mm



- Socket wrench extension
- Lubricant (WD-40)
- Hanger remover
- Floor jack handle or similar pole
- Hydraulic lift

### <u>Warning</u>

- Before removing original exhaust make sure to give it enough time for the system to cool down.
- If any items are missing please contact us at 972-233-0888 or info@topspeedauto.com
- We advise you have an experienced person or mechanic install the exhaust system

#### **Installation**

- Loosely fasten all nuts and bolts until everything is installed, then tighten the bolts down as you align the exhausts system
- It's helpful to have a friend hold the muffler in the position you like and start tightening down the bolts.
- Note: Use floor jack handle or similar to insert inside muffler to help maneuver the exhaust to fit in desired location then tighten bolts.
- Note: when you're underneath the car things look different then they do on the ground. Once you look at it, at a common angle it will look correct.